

DIS000AR

For dishwasher

1 coil

Original code:
104789
031957
812890043

ARISTON - ARDO



DIS000SM

For dishwasher

1 coil with led

Original code:
812890054

SMEG



DIS001AR

For dishwasher

1 coil with led

Original code:
063837
064697

ARISTON MERLONI



DIS001SM

For dishwasher

1 coil with led

Original code:
50247911006
054930

SMEG - INDESIT - ELECTROLUX



DIS000BO

For dishwasher

Original code:
41010261
490467

BOSCH



DIS000ZN

For dishwasher

1 coil

Original code:
1520806116

ZANUSSI



DIS000CY

For dishwasher

2 coils

Original code:
544000100
812890030
92213735
025683
104788

CANDY - ZEROWATT - SMEG - INDESIT - ARISTON



DIS000UN

For dishwasher

White
1 coil

UNIVERSAL



DIS001CY

For dishwasher

1 coil

With contact for signal lamp

Original code:
91943229

CANDY - ZEROWATT



DIS001UN

For dishwasher

Grey
1 coil

UNIVERSAL



DIS100BO

BOSCH

Upper dispenser
for washing machine

Original code:
265957



DIS100WH

WHIRLPOOL

For washing machine

Original code:
48124188025

