

HOME LAUNDRY AND DISHWASHERS

DISPENSERS SOAP, RINSE AID, BOXES

4812 418 68036

DETERGENT DISPENSER ASSEMBLY

Suitable For:
WHIRLPOOL DISHWASHER -
ADP256, ADP556, ADP566

ORIGINAL PART



4812 418 68119

DETERGENT DISPENSER ASSEMBLY

Suitable For:
WHIRLPOOL DISHWASHER -
ADP751

ORIGINAL PART



4812 418 68155

DETERGENT DISPENSER ASSEMBLY

Suitable For:
WHIRLPOOL DISHWASHER -
ADP962

ORIGINAL PART



4819 418 68207

DETERGENT DISPENSER ASSEMBLY

Suitable For:
WHIRLPOOL DISHWASHER -
ADG635W

ORIGINAL PART



A175

SOAP DISPENSER

OEM REF: LEY202AA2

Suitable For:
DEFY DISHWASHER - DISHMAID
MKI, MKII, MKIII, A, B, C, 3126,
3127, 3128; INDESIT
DISHWASHER - 111, 114, 115,
116, 2111, 2114, 2115, 2116, D310,




A172

SOAP DISPENSER GASKET

OEM REF: GCD004AA1

Suitable For:
DEFY DISHWASHER - DISHMAID
MKI, MKII, MKIII, A, B, C, 3126,
3127, 3128; INDESIT
DISHWASHER - 111, 114, 115,
116, 2111, 2114, 2115, 2116, D310,




A237

RINSE AID DISPENSER

OEM REF: LEW204CA1

Suitable For:
INDESIT DISHWASHER - 111,
114, 115, 116, 2111, 2114, 2115,
2116, D310, D340, D350, D360,
LS12, LS18, LS120, P12, P18



DY82

DETERGENT DISPENSER ASSEMBLY - 2 SOLENOIDS

OEM REF: LEZ201AA1

Suitable For:
DEFY DISHWASHER - RECENT
MODELS; INDESIT DISHWASHER
- D3000WI, D5000 SERIES, LEAD
KLEENMAID DISHWASHER -
CRYSTAL



G133

OEM REF: 104789

**DETERGENT DISPENSER
ASSEMBLY - SINGLE
SOLENOID**

Suitable For:

AEG DISHWASHER - FAVORIT
525; INDESIT DISHWASHER -
D3000WI, D3050WI, D4000
SERIES, DG5000, DG5100




G145

**DETERGENT DISPENSER
GASKET**

Suitable For:

SUITABLE WITH ALL
RECTANGULAR DUAL
DISPENSERS



08 1700

ORIGINAL PART

DETERGENT DISPENSER

Suitable For:

BOSCH / SIEMENS
DISHWASHERS

