


Spare parts suitable for: ***KSF***

Spare parts suitable for small appliances and single devices






Item	Order	Description	Model	OEM
1	105245	burner	RGS	30110144
2	105246	burner	KG	30110145
3	102232	thermocouple, 220mm	KG	40110304
3	102055	thermocouple, 450mm	RGS, München	40110305




Item	Order	Description	Model	OEM
1	101072	gas tap	München	40110201
2	101193	gas tap	KG	40110202 40110203




Item	Order	Description	Model	OEM
1	110152	knob	Uni	40110206
2	110737	knob		30110214
3	101757	aeration sleeve	RGS, KG	40110406 40110416




Item	Order	Description	Model	OEM
1	415315	2000W/230V	KG	40130306
2	416491	1500W/230V	RGS	40130305
3	380005	energy regulator	KG, RGS	40130205
4	110238	knob		40130206



Item	Order	Description	Model	OEM
1	359617	1000W/230V		40130401
2	359710	lamp holder		40130404
3	359620	300W/230V		40130403
4	359648	lamp holder		40130406



Item	Order	Description	Model	OEM
1	359625	500W/230V		40130402
2	359658	lamp holder complete		40130407




Item	Order	Description	Model	OEM
1	416492	1700W/230V, 800mm	München/kompakt	40130302
2	418066	2000W/230V, 1000mm	München	40130301
3	300023	switch	München,	40130203
4	110232	knob	München/kompakt	40130204



Item	Order	Description	Model	OEM
1	345388	switch, O-I		40130201
2	345393	switch, O-I-2		40130202
3	365002	capacitor, 4µF		40130108
3	365004	capacitor, 8µF		40130107
3	365030	capacitor, 12µF		40130106



Item	Order	Description	Model	OEM
1	101385	Minisit controller	Fryer	40110215
2	101136	piezoelectric igniter with fixing		-
3	100001	piezoelectric igniter		-
4	110068	knob		-



Item	Order	Description	Model	OEM
1	no longer available	pilot burner	fryer	40110302
2	100143	pilot burner/spare kit		
3	100008	piezoelectric igniter		40110301
4	375616	safety thermostat		40110303