

SWITCHES 2

ROLD series

ROLD D16 series



ROLD Domino series



ROLD D83 series



D16 series

ø16mm

1

2

3

4

5

6

7

8

item	order no.	description	colour
1	359241	lamp holder	grey
2	345536	lamp holder	black
3	359243	push button	grey
4	345538	push button	black
5	346202	push button	green
6	346203	push button	yellow
7	346204	push button	red
8	346205	push button	blue

1

2

3

4

5

6

item	order no.	description	colour
1	359247	indicator lamp cap	green
2	359246	indicator lamp cap	yellow
3	359245	indicator lamp cap	red
4	346228	indicator lamp cap	clear
5	346808	indicator lamp cap	blue
6	359244	blank cap	grey

ø13x17mm

1

2

3

4

5

6

7

item	order no.	description	colour
1	345537	lamp holder	grey
2	345627	lamp holder	black
3	345539	push button	grey
4	345621	push button	black
5	346809	push button	green
6	346572	push button	yellow
7	346810	push button	blue

Domino ST series

1

2

3

item	order no.	description	size (mm)	colour
1	345131	holder 1-fold	28,5x28,5	grey
2	346200	holder 2-fold	28,5x52,6	grey
3	346201	holder 3-fold	28,5x77,5	grey

1

2

3

item	order no.	description	size (mm)	colour
1	346498	holder 1-fold	28,5x28,5	black
2	346499	holder 2-fold	28,5x52,6	black
3	346500	holder 3-fold	28,5x77,5	black

push buttons without lens

1

2

3

4

5

6

7

item	order no.	colour
1	345132	green
2	345133	grey
3	346570	yellow
4	346816	black
5	346817	white
6	346818	blue
7	346819	red

push buttons with lens

1

2

3

4

5

6

item	order no.	colour
1	346210	green
2	346211	grey
3	346663	yellow
4	346501	black
5	346821	white
6	346822	blue

push buttons without lens with symbol

1

2

3

4

5

item	order no.	colour	symbol
1	345847	green	start
2	345848	blue	after rinse
3	345849	grey	regeneration
4	345850	grey	after rinse
5	345851	grey	start




item	order no.	colour	symbol
1	345852	green	drain
2	346265	grey	start
3	346253	grey	on - off
4	346254	grey	program
5	346255	grey	drain pump




item	order no.	colour	symbol
1	346256	grey	clock
2	346257	grey	after rinse
3	346258	grey	program 1 arrow
4	346259	grey	program 2 arrows

push buttons with lens and symbol



item	order no.	colour	symbol
1	346212	green	on - off
2	346266	grey	drain pump
3	346032	black	power
4	346820	black	coffee

indicator lamp caps




item	order no.	colour	symbol
1	346267	green	temperature
2	346268	green	limes
3	346269	green	boiler
4	346233	grey	blank cap



item	order no.	colour
1	346240	green
2	346241	yellow
3	346242	red
4	346243	clear
5	346244	blue

Domino SQ series




item	order no.	description	size (mm)	colour
1	345604	holder 1-fold	28,5x28,5	black
2	345602	holder 2-fold	28,5x52,6	black
3	345603	holder 3-fold	28,5x77,5	black

push buttons without lens



item	order no.	colour
1	346213	green
2	346214	yellow
3	346215	white
4	346216	blue
5	346494	black
6	346493	grey

push buttons with lens



item	order no.	colour
1	346217	green
2	346218	grey
3	346219	white
4	346220	blue
5	346492	black

push buttons without lens with symbol



item	order no.	colour	symbol
1	346225	green	cold rinse
2	346222	green	start
3	346224	green	regeneration
4	345609	black	start



item	order no.	colour	symbol
1	345611	black	cold rinse
2	345615	black	cycle selection
3	345613	black	drain pump
4	345618	black	cold rinse
5	346261	black	start

ROLD series

push buttons with lens and symbol




item	order no.	colour	symbol
1	346221	green	on - off
2	346223	green	drain pump
3	346230	black	power
4	345607	black	on - off
5	346231	black	time
6	345660	black	power




item	order no.	colour	symbol
1	346260	blue	cold rinse
2	345727	black	on - off
3	345726	black	light
4	345725	black	moisture
5	345745	black	fan

indicator lamp caps



item	order no.	colour
1	346245	green
2	346246	yellow
3	346247	clear
4	346248	blue




item	order no.	colour	symbol
1	346249	green	temperature
2	346250	green	cycle
3	346264	green	program
4	346263	yellow	temperature
5	345733	yellow	defrosting



item	order no.	colour	description
1	346229	grey	blank cap
2	345612	black	blank cap
3	345724	-	cap
4	345723	-	rotary knob
5	345721	-	holder for blank cap
6	345729	black	push button blank

turntables Domino ST/SQ



item	order no.	colour
1	346251	green/red
2	346262	grey/red
3	345608	black/green
4	346364	white/red
5	346824	black/red
6	346665	grey/green

Domino SR series standard 30x18,5mm

push buttons




item	order no.	colour	symbol
1	345739	black	-
2	345740	black	light
3	345737	black	on - off
4	345738	black	moisture



item	order no.	description	colour
1	345731	turntable	black/red
2	345741	thermostat cup	-
3	345723	rotary knob	-

Domino SR series /special 24,6x18,7mm
push buttons




item	order no.	description	colour	symbol
1	345732	push button	black	fan
2	345746	push button	black	light
3	345734	indicator lamp 230V	green	-
4	345428	indicator lamp 230V	red	-
5	345733	indicator lamp cap	yellow	defrosting
6	345731	turntable	-	-

switches/push buttons



item	order no.	description	contacts
1	345722	switch	1 NO
	345130	push button	1 NO
2	345719	switch	1 CO
	346250	push button	1 CO
3	345720	switch	2 NO
	345980	push button	2 NO



item	order no.	description	contacts
1	345605	switch	2 CO
	345606	push button	2 CO
2	345651	switch	2 CO
	345650	push button	2 CO



item	order no.	description	voltage	colour
1	345601	lamp holder	-	
	359129	signal element	24V	clear
	359130	signal element	230V	clear
2	359132	signal element	230V	green
	359131	signal element	400V	clear
	359133	signal element	400V	green
	359350	signal element	230V	blue

D83 SB series
push buttons with symbol



item	order no.	colour	symbol
1	345827	grey	Sinus
2	345829	grey	drain pump
3	346827	grey	regeneration
4	346831	grey	I - II




item	order no.	colour	symbol
1	345828	yellow	start
2	346832	green	start
3	346833	grey	cooling

switches/push buttons



item	order no.	description	contacts
1	345824	push button	2 CO
2	345825	push button	1 CO
3	345826	switch	2 CO



item	order no.	description
1	346828	housing
2	345830	blank cap

D83 CM series standard
push buttons



item	order no.	description	colour
1	345833	push button	grey
	345834	push button	yellow
2	346829	push button	white
	346830	push button	black

switches/push buttons



item	order no.	description	contacts
1	345832	push button	1 CO
2	345831	switch	2 CO