

Spare parts suitable for:
THIELMANN



Open tops (gas)



Item	Order	Description	Model	OEM
1	105873	burner cover C	HG2/4/6, HGB4/6, HGBE4/6	540486, 144340
1	105874	burner cover D/E		540487, 144341
2	105871	burner C		193466
2	105870	burner D		193467
2	105869	burner E		193468



Item	Order	Description	Model	OEM
1	101095	gas tap	HG2/4/6,	144424
2	111832	knob	HGB4/6,	540448
3	111835	symbol	HGBE4/6	540449




Item	Order	Description	Model	OEM
1	102829	pilot burner C	HG2/4/6, HGB4/6, HGBE4/6	540920, 193301
2	102830	pilot burner D/E		540921, 193303
3	102054	thermocouple, 320mm		144305
3	102056	thermocouple, 600mm		144306

Open tops (electric)



Item	Order	Description	Model	OEM
1	490088	2500 W/400 V	HE2/4/6, HEB4/6/6W	144170
1	490090	4000 W/400 V		144171
2	359027	signal lamp/green		143841
3	359048	signal lamp/yellow		540180



Item	Order	Description	Model	OEM
1	300106	7-position switch	HE2/4/6, HEB4/6/6W	141187
2	111831	knob		144104, 540422
3	111838	symbol		144107, 540477

Open tops (solid top/gas)





Item	Order	Description	Model	OEM
1	105875	burner	HGG4, HGGB4	144818
2	101095	gas tap		144424
3	111832	knob		540448
4	111835	symbol		540449




Item	Order	Description	Model	OEM
1	100061	pilot burner	HGG4, HGGB4	140928
2	102219	thermocouple		136030
3	100704	electrode		-



Ovens (electric)



Item	Order	Description	Model	OEM
1	418223	2000 W/400 V		540471, 144168
1	418222	2800 W/400 V	HGBE4/6, HEB4/6/W6	540831, 144169
2	375695	safety thermostat		540470, 251116



Item	Order	Description	Model	OEM.
1	300190	switch		141924, 540472
2	111831	knob	HGBE4/6, HEB4/6/W6	540422, 144104
3	111833	symbol		540469, 144108



Item	Order	Description	Model	OEM
1	375038	thermostat		139783
2	111831	knob		144104, 540422
3	111834	symbol	HGBE4/6, HEB4/6/W6	144109, 540457
4	359027	signal lamp/green		143841
5	359048	signal lamp/yellow		540180

Ovens (mechanical)



Item	Order	Description	Model	OEM
1	700600	spring/left	HGB4/6, HGBE4/6, HEB4/6/W6	540453, 150095
2	700601	spring/right		141039, 540454



2

Item	Order	Description	Model	OEM
1	100008	piezoelectric igniter	HGG4,	144333
2	100017	ignition cable	HGGB4	-

Ovens (gas)

no picture!

1



3



4



Item	Order	Description	Model	OEM.
1	105876	burner		193660
2	101900	thermostat	HGB4/6,	144428
3	111832	knob	HGGB4	540448
4	111839	symbol		540456



2




Item	Order	Description	Model	OEM
1	102831	pilot burner	HGB4/6, HGGB4	540450, 144400
2	102076	thermocouple, 850 mm		144404




2

Item	Order	Description	Model	OEM
1	100008	piezoelectric igniter	HGB4/6,	144333
2	100701	electrode	HGGB4	-

Bains-marie (electric)



Item	Order	Description	Model	OEM
1	415760	1800W/230V	WE2/1-3/1, WEW2/1-3/1	540463, 144167
2	520323	gasket		144334
3	520324	flange		144343



Item	Order	Description	Model	OEM
1	375019	thermostat	WE2/1-3/1, WEW2/1-3/1	144180
2	111831	knob		144104
3	111840	symbol		144108



Item	Order	Description	Model	OEM
1	300001	switch	WE2/1-3/1, WEW2/1-3/1	540461, 142752
2	359027	signal lamp/green		143841
3	359048	signal lamp/yellow		540180


Fry tops (gas)



Item	Order	Description	Model	OEM
1	105877	burner	BGG, BGR	193635
2	101095	gas tap		144424
3	111832	knob		540448
4	111835	symbol		540449




Item	Order	Description	Model	OEM
1	102831	pilot burner	BGG, BGR	540450, 144400
2	100701	electrode		-
3	102219	thermocouple, 450mm		136030



Item	Order	Description	Model	OEM
1	100008	piezoelectric igniter	BGG, BGR	144333
2	100018	ignition cable		-

Fry tops (electric)




Item	Order	Description	Model	OEM
1	418238	2000W/400V	BEG, BEG-R, BER, BEG-C	540458, 143831
2	375706	safety thermostat		540406, 144095
3	300001	switch		540461, 142752




Item	Order	Description	Model	OEM
1	375038	thermostat	BEG, BEG-R, BER, BEG-C	139783
2	111831	knob		540422, 144104
3	111834	symbol		540457, 144109
4	359027	signal lamp/green		143841
5	359048	signal lamp/yellow		540180


Fryers



Item	Order	Description	Model	OEM
1	418263	7200 W/230 V	FE2x8, FE16	540441, 144187
2	375707	safety thermostat		540443, 144182
3	345060	micro switch		141907



Item	Order	Description	Model	Vergleichs-Nr.
1	375708	thermostat	FE2x8, FE16	540444, 143766
2	111831	knob		540422, 144104
3	111869	symbol		541138



Item	Order	Description	Model	OEM
1	300193	switch	FE2x8, FE16	540445, 143765
2	111831	knob		510422, 144104
3	111870	symbol		



Item	Order	Description	Model	OEM
1	345060	micro switch	FE2x8, FE16	141907
2	346426	push button		130406
3	359027	signal lamp/green		143841
4	359048	signal lamp/yellow		540180



Pos.	Order	Description	Model	OEM
1	970448	fryer basket	FE2x8, FE16	540446, 143772

Tilting bratt pans (gas)

no picture!

1


no picture!

2

no picture!

3

Item	Order	Description	Model	OEM
1	105917	burner/complete	PG2/1	144615
2	105919	burner/right	PG3/1	144558
3	105918	burner/left		144557



Item	Order	Description	Model	OEM
1	106027	gas thermostat	PG2/1, PG3/1	540403, 144561
2	111832	knob		544448
3	111839	symbol		544456




Item	Order	Description	Model	OEM
1	102831	pilot burner	PG2/1, PG3/1	540450, 144400
2	100701	electrode		-
3	100008	piezoelectric igniter		144333
4	102076	thermocouple		144404


T

Suitable for Thielmann

Tilting bratt pans (electric)



Item	Order	Description	Model	OEM
1	415594	2565 W/400 V	PE2/1, PE3/1,	182329, 143648
2	375706	safety thermostat	PE2/1M, PE3/1M	540406, 144095
3	380213	contactor		144764, 143815



Item	Order	Description	Model	OEM
1	300001	switch		142752, 540461
2	375038	thermostat	PE2/1, PE3/1,	139783
3	111831	knob	PE2/1M, PE3/1M	144104, 540422
4	111834	symbol		144109, 540457

Tilting bratt pans (mechanical)



Item	Order	Description	Model	OEM
1	690901	hand wheel	universal	540403, 144139
2	700513	gas pressure spring	2/1	540478, 144662
3	700515	gas pressure spring	3/1	541124, 144661



Pos.	Order	Description	Model	OEM
1	693447	cover rotating joint	universal	144138

Tilting bratt pans (motor drive)




Item	Order	Description	Model	OEM
1	345707	contactor block		143052
2	346271	push button	PE2/1M, PE3/1M	144412
3	346435	symbol		144415

Boiling pans (gas)



Item	Order	Description	Model	OEM
1	105905	burner	universal	541545, 141960
2	101166	ignition control module		540409, 144750




Item	Order	Description	Model	OEM
1	100062	pilot burner	universal	130132
2	100085	pilot burner	KG100WA	140928


Boiling pans (electric)



Item	Order	Description	Model	OEM
1	415604	3000 W/3 phases 230 V	KE150	541218, 143833
2	418286	6000 W/3 phases 230 V	KE40, KE60	540821, 143834
3	418270	9000 W/3 phases 230 V	KE80-150, KE60K-150K	540717, 143836




Item	Order	Description	Model	OEM
1	415405	6000W/3 phases 230 V	KER150-400	144346
2	418287	9000W/3 phases 230 V	KER100-400	144347
3	415653	600W/230 V	universal	143895



Item	Order	Description	Model	OEM
1	300104	4-position switch	KE_, KE_K, KER_	141188
2	111831	knob		144104
3	111895	symbol (4-tacts)		540432




Item	Order	Description	Model	OEM
1	300074	switch (0-I)		144696
2	111831	knob	KG	141188
3	111896	symbol (0-I-0-I)		-



Item	Order	Description	Model	OEM
1	380213	contactor	KE_, KE_K, KER_	144764
2	380261	contactor	KER150-400	130274
3	380265	contactor	KER250-400	144345



Item	Order	Description	Model	OEM
1	345707	contactor block		143052
2	346271	push button	KG	144412
3	346435	key plate		144411




Item	Order	Description	Model	OEM
1	541408	pressure switch		540416, 143896
2	375519	safety thermostat	universal	540414, 143830
3	380036	energy regulator		538255, 221406

Boiling pans (mechanical)



Item	Order	Description	Model	OEM
1	693450	cover rotating joint	KE_K, KE40-150, KG80-100	144122
1	693449	cover rotating joint	KG40-60	144701
2	693448	cover rotating joint	KER_	144466




Item	Order	Description	Model	OEM
1	111831	knob		144104
2	111894	symbol (1-10)		540826
3	359027	signal lamp/green	universal	143841
4	359048	signal lamp/yellow		540180
5	359026	signal lamp/red		540181




Item	Order	Description	Model	OEM
1	514355	mixing valve	universal	540830, 144132
2	514332	rotating arm		144407
3	514272	steam trap		540408, 144742



Item	Order	Description	Model	OEM
1	514356	handle	universal	151905
2	514358	push button/blue		151904
3	514359	push button/red		151903



Item	Order	Description	Model	OEM
1	540137	drain cock 1 1/2"	KE_, KG_	130176
2	540138	drain cock, 2"	KER_	130177



Item	Order	Description	Model	OEM
1	514354	safety valve	universal	144749
2	541398	manometer		144192

Boiling pans (motor drive)



Item	Order	Description	Model	OEM
1	345060	micro switch, NO	KE_K	141907
2	345061	micro switch, NC		144412



Item	Order	Description	Model	OEM
1	345707	contactor block	KE_K	143052
2	346271	push button		144412
3	346435	key plate		144415