

## Hidrostat i

### Hidrostat

**10.60.030**



HD 505 EA 101

Broj kontakata: 7

Nivo II (Off/On) 230 ÷ 160

Nivo I (Off/On) 170 ÷ 130

Sigurnosni nivo (Off) 300

Metalflex, Slovenija

### Hidrostat

**10.60.040**



HD 505 AJ 101

Broj kontakata: 3

Nivo (Off/On) 200 ÷ 160

Metalflex, Slovenija

### Hidrostat

**10.60.050**



HD 505 CH 101

Broj kontakata: 6

Nivo I (Off/On) 170 ÷ 130

Nivo II (Off/On) 210 ÷ 160

Metalflex, Slovenija

### Hidrostat

**10.60.060**



HD 528 V5CC

Broj kontakata: 7

Gorenje šifra: 618672

Nivo I (On/Off) 120 ÷ 160

Sigurnosni nivo (Off) 300

Nivo II (On/Off) 150 ÷ 190

Metalflex, Slovenija

### Hidrostat

**10.60.061**



HD 528 G5CC

Broj kontakata: 7

Gorenje šifra: 598509

Nivo I (On/Off) 115 ÷ 150

Sigurnosni nivo (Off) 300

Nivo II (On/Off) 160 ÷ 200

Metalflex, Slovenija

### Hidrostat

**10.60.070**



HD 505 ET 101

Broj kontakata: 7

Gorenje šifra: 618671

Nivo II (Off/On) 190 ÷ 150

Nivo I (Off/On) 160 ÷ 120

Sigurnosni nivo (Off) 300

Metalflex, Slovenija

### Hidrostat

**10.60.071**



HD 505 EP 101

Broj kontakata: 7

Gorenje šifra: 618670

Nivo I (Off/On) 110 ÷ 80

Nivo II (Off/On) 130 ÷ 95

Sigurnosni nivo (Off) 300

Metalflex, Slovenija

### Hidrostat

**10.60.073**



HD 505 GA 201

Broj kontakata: 4

za Gorenje šifru: 587573

Nivo (On/Off) 105 ÷ 75

Sigurnosni nivo (Off) 300

Metalflex, Slovenija

### Hidrostat

**10.60.600**



TG-600

250.03301.10A

16 A/ 250 V~

T&G, Italija