

Spare parts suitable for: **JÜNGER**

Spare parts suitable for small appliances and single devices



Chargrills (gas)



Item	Order	Description	Model	OEM
1	104218	burner	0282_	0433282
2	104220	burner	0280-/0285_, 0286_	0433280
3	101400	injector	knob	0431430



Item	Order	Description	Model	OEM
1	100005	piezoelectric igniter		0401000
2	100743	electrode	0260_	0401120
3	101051	solenoid coil, 11 mm	0269_	0431440
			0270_	




Item	Order	Description	Model	OEM
1	101193	gas tap		0431300, 0431310
2	110149	knob	0280_, 0282-, 0285_, 0286	0431320
3	102054	thermocouple		0431410
4	102067	nut, M8x1		-
5	101051	solenoid coil, 11 mm		0431440

Sausage warmers




Item	Order	Description	Model	OEM
1	101219	burner		0434240
2	101400	injector	0251_, 0255_, 0256, 0257	0431420
3	101194	gas tap		0431100, 0431110
4	110147	knob		0431120
5	101051	solenoid coil		

Sausage roasters (gas)




Item	Order	Description	Model	OEM
1	104221	burner (aluminium)	0260	0431260
2	104222	burner (refined steel)	0269, 0270	0431270
3	101400	injector	universal	0431430




Item	Order	Description	Model	OEM
1	101073	gas tap		0431200, 0431210
2	110148	knob	0260_	0431220
3	102054	thermocouple	0269_	0431410
4	102067	nut, M8x1	0270_	

Sausage roasters (electrical)




Item	Order	Description	Model	OEM
1	415343	1500W/230V		0421000
2	415344	2500W/230V	0271_, 0272_	0421100
3	415346	2500W/230V		0421300




Item	Order	Description	Model	OEM
1	380005	energy regulator	0271_, 0272_	0423110, 0423100
2	110238	knob	0273_, 0274_	0423120
3	359140	control lamp	0276_	0426000

Sausage warmers/steamers



Item	Order	Description	Model	OEM
1	415754	600 W/230 V	0250_, 0252_, 0253_, 0254_	0420000
2	415342	2000 W/230 V	0258	0445258
3	375115	safety thermostat		0422000
4	359140	signal lamp		0425000



Item	Order	Description	Model	OEM
1	375114	thermostat, 1-pole	0250_, 0252_, 0253_, 0254	0422100
2	110119	knob		0422120