


Spare parts suitable for: **MALAG**

Spare parts suitable for modular ranges



Spare parts suitable for single devices



Open tops (gas)



Item	Order	Description	Model	OEM
1	105792	burner cover, 3200 kcal		112232
2	105793	burner ring/small, 3200 kcal	AG4-_, AG8-_,	177768
3	105794	burner ring/large, 3200 kcal	AG12-_,	177792
4	105795	burner Vars	AGE8-_, AGE12-_,	199992
1 - 4	105796	radial burner/complete		112275



Item	Order	Description	Model	OEM
1	105797	burner cover, 5000 kcal		112224
2	105798	burner ring/small, 5000 kcal	AG4-_, AG8-_,	177776
3	105799	burner ring/large, 5000 kcal	AG12-_,	177806
4	105800	burner Vars	AGE8-_, AGE12-_,	199992
1 - 4	105801	radial burner/complete		112267



Item	Order	Description	Model	OEM
1	105802	gas tap EGA	AG4-_, AG8-_, AG12-_,	112721, 112722
2	101624	gas tap PEL	AGE8-_, AGE12-_,	112721, 112722
3	110217	knob	-	179922




Item	Order	Description	Model	OEM
1	100075	pilot burner		112666, 112667
2	100600	pilot burner filter	AG4-_, AG8-_, AG12-_,	112526
3	100601	cover	AGE8-_, AGE12-_,	112668
4	100214	jet FL (0,16mm)		112534
4	100215	jet EG (0,28mm)		162558

Open tops (electric)




Item	Order	Description	Model	OEM
1	490016	2000 W/230 V, 180mm		117854
2	490020	2600 W/230 V, 220mm	E7	117846
3	490065	2000 W/230 V, 220x220mm		161632
3	490066	2600 W/230 V, 220x220mm		161624



Item	Order	Description	Model	OEM
1	490065	2000 W/230 V, 220x220mm		161632
1	490066	2600 W/230 V, 220x220mm		161624
1	490067	2000 W/400 V, 220x220mm		161634
1	490068	2600 W/400 V, 220x220mm	E8	161635
2	490056	3000 W/230 V, 300x300mm		117897
2	490071	4000 W/230 V, 300x300mm		117889
2	490057	3000 W/400 V, 300x300mm		117902
2	490074	4000 W/400 V, 300x300mm		117890




Item	Order	Description	Model	OEM
1	300025	7-position switch, 16A	E7_, E8_	106070
2	300103	4-position switch, 32A	E8_	106062
3	300106	7-position switch, 32A		106072




Item	Order	Description	Model	OEM
1	110211	4-position knob	E7_, E8_	144452
2	110212	7-position knob		143871

Ovens (electric)



Item	Order	Description	Model	OEM
1	415610	1600W/230V	E7_	143790
2	480063	450W/230V	E8_	117994




Item	Order	Description	Model	OEM
1	300006	switch	E7_	143774
2	375012	thermostat		143702
3	110214	knob		144208



Item	Order	Description	Model	OEM
1	375685	thermostat	E8_	105784, 105783
2	110214	knob		106119
3	359117	signal lamp holder		144266
4	359602	glow lamp E14		105473

Hot cupboards (electric)



Item	Order	Description	Model	OEM.
1	415323	1600W/230V	E7_	105643
2	418225	1000W/230V	E8_	105597



Item	Order	Description	Model	OEM
1	375188	thermostat, 3-pole	E7_	105813
2	375031	thermostat, 2-pole		105864
3	375546	thermostat, 1-pole		105740



Item	Order	Description	Model	OEM
1	110213	knob	E7_	106100
2	359117	signal lamp holder		161446
3	359602	glow lamp, 230 V		105473

Fry tops (electric)




Item	Order	Description	Model	OEM
1	480035	500 W/230 V	ESBG7_	144266
2	480063	450 W/230 V	ESBG8_	117994



Item	Order	Description	Model	OEM
1	375685	thermostat	ESBG7_	105783
2	110214	knob		106119
3	359117	signal lamp holder	ESBG8_	161446

Bains-marie (electric)




Item	Order	Description	Model	OEM
1	415322	2600W/230V	EW7_	105627
2	415323	1600W/230V		105619, 105643
3	418225	1000W/230V	EW7	105597

Fryers (electric)



Item	Order	Description	Model	OEM
1	418226	6500W/230V	EF7_	144436
2	375686	safety thermostat	EF8_	174963



Item	Order	Description	Model	OEM
1	375687	thermostat		105792
2	110219	knob	EF7_	106127
3	359117	signal lamp holder	EF8_	161446

Fryer baskets



Pos.	Order	Description	Model	OEM
1	970436	300x180x160mm	EF7_	113123
2	970437	320x380x180mm	EF8_	113131

Tilting bratt pans (electric)




Item	Order	Description	Model	OEM
1	480035	500W/230V	EK7	144266
2	480032	700W/230V	EK8	118028



Item	Order	Description	Model	OEM
1	375685	thermostat		105783
2	110214	knob	EK7	106119
3	359117	signal lamp holder	EK8	161446
4	359602	glow lamp, 230V		105473


Boiling pans (electric)



Item	Order	Description	Model	OEM
1	415581	3000W/230V		105716
2	415263	4500W/230V	ESK7	105724
2	415663	6000W/230V	ESK8	105732
3	415653	600W/230V		105708



Item	Order	Description	Model	OEM
1	400073	level regulator		177965
2	541022	pressure switch	ESK7	161357
3	370364	solenoid valve, 3/8"	ESK8	161363



Item	Order	Description	Model	OEM
1	375709	thermostat		172146
2	375710	limiter	ESK7	105767
3	375711	thermostat	ESK8	172154




Item	Order	Description	Model	OEM
1	540136	drain cock, 1 1/4"		114383
2	540137	drain cock, 1 1/2"	ESK7	114375
3	540138	drain cock, 2"	ESK8	114367



Item	Order	Description	Model	OEM
1	540079	funnel intake tap		114227
2	540013	pressure relief valve	ESK7	114405
3	540010	pressure relief valve, 3/8"	ESK8	113891
3	540011	pressure relief valve, 1/2"		113905

Pizza ovens/Bred ovens (electrical)

Item	Order	Description	Model	OEM
1	480063	450 W/230 V, 700 mm	EBP7_07, EB7_07	117994
1	480057	500 W/230 V, 1030 mm	EB7_10	117978
1	480065	700 W/230 V, 1030 mm	EBP7_10	117951
1	480066	900 W/230 V, 1300 mm	EBP7_13	117935
2	550120	screw connection	universal	117919



Item	Order	Description	Model	OEM
1	375032	thermostat, 50 - 300 °C	EB_	105784
1	n. l. a.	thermostat, 130 - 370 °C	EBP_	-
2	375685	thermostat, 50 - 300 °C	EB_	105784
2	375101	thermostat, 130 - 370 °C	EBP_	105849
2	375225	thermostat, 100 - 400 °C		105847



Item	Order	Description	Model	OEM
1	110214	knob, 300 °C	EB_	106119
2	110216	knob, 370 °C	EBP_	106135
3	111783	knob, 400 °C		143872, 199992



Item	Order	Description	Model	OEM
1	359117	signal lamp holder	universal	161446
2	359602	glow lamp		105473