




| Detalji o artiklu      |                 |
|------------------------|-----------------|
| <b>Artikal:</b>        | PROGRAMATOR 111 |
| <b>Kataloski broj:</b> | <b>249645</b>   |
| <b>Dimenzije:</b>      |                 |
| <b>Vrsta:</b>          | VEŠ MAŠINE      |
| <b>Podvrsta:</b>       | PROGRAMATORI    |




| Detalji o artiklu      |                    |
|------------------------|--------------------|
| <b>Artikal:</b>        | PROGRAMATOR 501-01 |
| <b>Kataloski broj:</b> | <b>255613</b>      |
| <b>Dimenzije:</b>      |                    |
| <b>Vrsta:</b>          | VEŠ MAŠINE         |
| <b>Podvrsta:</b>       | PROGRAMATORI       |




| Detalji o artiklu      |                    |
|------------------------|--------------------|
| <b>Artikal:</b>        | PROGRAMATOR 701-02 |
| <b>Kataloski broj:</b> | <b>279276</b>      |
| <b>Dimenzije:</b>      |                    |
| <b>Vrsta:</b>          | VEŠ MAŠINE         |
| <b>Podvrsta:</b>       | PROGRAMATORI       |



| Detalji o artiklu      |                    |
|------------------------|--------------------|
| <b>Artikal:</b>        | PROGRAMATOR 320-01 |
| <b>Kataloski broj:</b> | <b>12P002</b>      |
| <b>Dimenzije:</b>      |                    |
| <b>Vrsta:</b>          | VEŠ MAŠINE         |
| <b>Podvrsta:</b>       | PROGRAMATORI       |




| Detalji o artiklu      |                    |
|------------------------|--------------------|
| <b>Artikal:</b>        | PROGRAMATOR 700-02 |
| <b>Kataloski broj:</b> | <b>12P004</b>      |
| <b>Dimenzije:</b>      |                    |
| <b>Vrsta:</b>          | VEŠ MAŠINE         |
| <b>Podvrsta:</b>       | PROGRAMATORI       |




| Detalji o artiklu      |                    |
|------------------------|--------------------|
| <b>Artikal:</b>        | PROGRAMATOR 700-02 |
| <b>Kataloski broj:</b> | <b>12P004</b>      |
| <b>Dimenzije:</b>      |                    |
| <b>Vrsta:</b>          | VEŠ MAŠINE         |
| <b>Podvrsta:</b>       | PROGRAMATORI       |



| Detalji o artiklu |                  |
|-------------------|------------------|
| Artikal:          | PROGRAMATOR 790C |
| Kataloski broj:   | 12P038           |
| Dimenzije:        |                  |
| Vrsta:            | VEŠ MAŠINE       |
| Podvrsta:         | PROGRAMATORI     |



| Detalji o artiklu |                            |
|-------------------|----------------------------|
| Artikal:          | PROGRAMATOR 2000/2005/6551 |
| Kataloski broj:   | 479331                     |
| Dimenzije:        |                            |
| Vrsta:            | VEŠ MAŠINE                 |
| Podvrsta:         | PROGRAMATORI               |



| Detalji o artiklu |                      |
|-------------------|----------------------|
| Artikal:          | PROGRAMATOR TMX 1720 |
| Kataloski broj:   | 12P037               |
| Dimenzije:        |                      |
| Vrsta:            | VEŠ MAŠINE           |
| Podvrsta:         | PROGRAMATORI         |





| Detalji o artiklu |                     |
|-------------------|---------------------|
| Artikal:          | PROGRAMATOR EC 4439 |
| Kataloski broj:   | 550887              |
| Dimenzije:        |                     |
| Vrsta:            | VEŠ MAŠINE          |
| Podvrsta:         | PROGRAMATORI        |



| Detalji o artiklu |                 |
|-------------------|-----------------|
| Artikal:          | PROGRAMATOR 122 |
| Kataloski broj:   |                 |
| Dimenzije:        |                 |
| Vrsta:            | VEŠ MAŠINE      |
| Podvrsta:         | PROGRAMATORI    |
| Namena:           | LEDOMAT         |



| Detalji o artiklu |                      |
|-------------------|----------------------|
| Artikal:          | PROGRAMATOR 222-B/C  |
| Kataloski broj:   |                      |
| Dimenzije:        |                      |
| Vrsta:            | VEŠ MAŠINE           |
| Podvrsta:         | PROGRAMATORI         |
| Namena:           | OBOD MENJA PG 302-01 |



| Detalji o artiklu      |                          |
|------------------------|--------------------------|
| <b>Artikal:</b>        | PROGRAMATOR 345          |
| <b>Kataloski broj:</b> |                          |
| <b>Dimenzije:</b>      |                          |
| <b>Vrsta:</b>          | VEŠ MAŠINE               |
| <b>Podvrsta:</b>       | PROGRAMATORI             |
| <b>Namena:</b>         | KONČAR P-15,P-151 itd... |



| Detalji o artiklu      |                                                          |
|------------------------|----------------------------------------------------------|
| <b>Artikal:</b>        | PROGRAMATOR 346                                          |
| <b>Kataloski broj:</b> |                                                          |
| <b>Dimenzije:</b>      |                                                          |
| <b>Vrsta:</b>          | VEŠ MAŠINE                                               |
| <b>Podvrsta:</b>       | PROGRAMATORI                                             |
| <b>Namena:</b>         | KONČAR P-15T,P151T itd..(koji imaju kapilarni termostat) |